
Installation WT500

Procedure Firmware Upgrade Procedure Using a USB memory

DATE: January 31, 2020

This explains how to upgrade your version of the WT500 (Model: 760201/760202/760203) firmware.
Please perform the following procedure.

1 Preparation

1.1 Unzip the downloaded file. The zip file contains:

1. WT500lz.bin
2. procedure_wt500e.pdf (this file)

1.2 Make sure you have a formatted USB memory ready before beginning the upgrade procedure.

1.3 Copy the firmware file *WT500lz.bin* to the root directory of the prepared media.

2 Installation

2.1 All settings other than date/time settings will be initialized during the upgrade, so you should write down the settings or save them if needed after the upgrade.

2.2 Turn OFF the power to the WT500.

2.3 Insert the disk into the WT500's USB memory drive.

2.4 Turn the WT500 ON while holding down the [PAGE UP] key.



2.5 Wait up to 1 minute while the program automatically writes the new firmware data to memory.

2.6 "Successful system update" is displayed, then the instrument is restarted automatically.

3 Checking the Installation

3.1 Check that the initialize message appears after the instrument starts up.

3.2 Press the MISC key, then the System Overview function key to confirm that the version number under Soft Version is correct.

3.3 If necessary, load the settings that were saved in step 2-1.